

# Ultra Rx

## Lens Retrieval from UV Light Module

1. Detached remaining lenses off the Spindle arm Suction cups.
2. Go to Lamp removal screen. Press Lamp Remove button.
3. Turn off the power to the machine and disconnect power cord from the electrical outlet.
4. With the power off and disconnected from the outlet, open the back door of the Ultra Rx.
5. Remove the two pan head allen screws that hold the UV Light Module in the carriage.
6. After the screws are removed, remove the UV Light Module from the carriage.
7. Remove the lens from the lamp area ~**Caution Lamp Module may be hot.**
8. Check for lens debris and if lamp and reflectors are clean, return UV Light Module to carriage, secure lamp with screws and return to machine operations. If lamp and reflectors are not clean and cannot be cleaned, replace UV Light Module with a new and return to machine operation.